




SPARE PARTS LIST

SCARIFIER

BMP 335, 2022-04

BMP 335
STEERHANDLE, COMPLETE




STEERING

BMP 335, 2022-04

Ref	Part No	Description	Remark	QTY KIT
1	536546101	TBD	PLATE	1
2	533 82 94-01	POTENTIOMETER	POTENTIOMETER	2
3	534 65 44-01	JOYSTICK	JOYSTICK	2
4	533 99 04-01	BUTTON	BUTTON	2
5	533 74 92-01	STOP	STOP	1
6	536977501	TBD	METER	1
7	900 00 00-02	DUMMY PART	DUMMY PART	1
8	900 00 00-02	DUMMY PART	DUMMY PART	11
9	533 38 74-01	SWITCH	SWITCH	1
10	533 28 91-01	KEY	KEY	1
11	533 81 08-01	CORD	CORD	1
12	534 40 91-01	BOX	BOX	1
13	536977601	TBD	SEAL	1
14	534 41 64-01	COVER	COVER	1
15	535 19 00-01	BAR	BAR	1
16	533 40 76-01	TUBE	TUBE	2
17	533 26 76-01	BUMPER	BUMPER	1
18	900 00 00-02	DUMMY PART	DUMMY PART	4

BMP 335
DRIVE UNIT RH




DRIVE UNIT

BMP 335, 2022-04

Ref	Part No	Description	Remark	QTY KIT
1	534 52 29-01	BRACKET	BRACKET	1
2	534 23 97-01	DRIVE MOTOR	DRIVE MOTOR	1
3	535 36 57-01	SPACER	SPACER	1
4	534 85 59-01	SPACER	SPACER	1
5	535 63 26-01	HOUSING	HOUSING	1
6	535 20 88-01	LOCKING PLATE	LOCKING PLATE	1
7	534 86 91-01	SPRING	SPRING	6
8	534 77 48-01	PLATE	PLATE	1
9	534 75 95-01	BEARING	BEARING	1
10	534 61 97-01	FORK	FORK	1
11	534 52 23-01	AXLE	AXLE	1
12	534 75 86-01	BEARING	BEARING	2
13	534 93 90-01	WHEEL	WHEEL	1
14	900 00 00-02	DUMMY PART	DUMMY PART	2
15	900 00 00-02	DUMMY PART	DUMMY PART	2
16	534 75 93-01	BEARING	BEARING	2
17	535 62 60-01	BLOCK	BLOCK	1
18	534 79 19-01	SEAL	SEAL	1
19	534 75 92-01	BEARING	BEARING	1
20	535 17 39-01	AXLE	AXLE	1
21	535 21 66-01	MOUNTING PLATE	MOUNTING PLATE	1
22	535 22 47-01	PEDAL	PEDAL	1
23	533 26 76-01	BUMPER	BUMPER	1
24	900 00 00-02	DUMMY PART	DUMMY PART	1
25	535 18 01-01	AXLE	AXLE	1
26	900 00 00-02	DUMMY PART	DUMMY PART	1
27	900 00 00-02	DUMMY PART	DUMMY PART	3
28	534 84 72-01	BLOCK	BLOCK	1
29	534 86 82-01	SPRING	SPRING	1
30	900 00 00-02	DUMMY PART	DUMMY PART	2
31	534 87 23-01	BRACKET	BRACKET	1
32	900 00 00-02	DUMMY PART	DUMMY PART	5
33	900 00 00-02	DUMMY PART	DUMMY PART	5
34	900 00 00-02	DUMMY PART	DUMMY PART	2

BMP 335
DRIVE UNIT LH

36




DRIVE UNIT

BMP 335, 2022-04

Ref	Part No	Description	Remark	QTY KIT
1	900 00 00-02	DUMMY PART	DUMMY PART	1
2	900 00 00-02	DUMMY PART	DUMMY PART	1
3	534 75 86-01	BEARING	BEARING	2
4	534 93 90-01	WHEEL	WHEEL	1
5	534 52 23-01	AXLE	AXLE	1
6	534 61 97-01	FORK	FORK	1
7	534 75 95-01	BEARING	BEARING	1
8	534 77 48-01	PLATE	PLATE	1
9	534 86 91-01	SPRING	SPRING	6
10	900 00 00-02	DUMMY PART	DUMMY PART	8
11	534 85 59-01	SPACER	SPACER	1
12	535 63 26-01	HOUSING	HOUSING	1
13	535 20 88-01	LOCKING PLATE	LOCKING PLATE	1
14	900 00 00-02	DUMMY PART	DUMMY PART	4
15	534 52 27-01	BRACKET	BRACKET	1
16	534 23 97-01	DRIVE MOTOR	DRIVE MOTOR	1
17	900 00 00-02	DUMMY PART	DUMMY PART	7
18	900 00 00-02	DUMMY PART	DUMMY PART	3
19	534 87 22-01	BRACKET	BRACKET	1
20	900 00 00-02	DUMMY PART	DUMMY PART	2
21	534 84 72-01	BLOCK	BLOCK	1
22	900 00 00-02	DUMMY PART	DUMMY PART	2
23	534 75 92-01	BEARING	BEARING	1
24	900 00 00-02	DUMMY PART	DUMMY PART	1
25	535 18 01-01	AXLE	AXLE	1
26	900 00 00-02	DUMMY PART	DUMMY PART	1
27	535 17 16-01	AXLE	AXLE	1
28	900 00 00-02	DUMMY PART	DUMMY PART	3
29	535 21 66-01	MOUNTING PLATE	MOUNTING PLATE	1
30	535 22 47-01	PEDAL	PEDAL	1
31	533 26 76-01	BUMPER	BUMPER	1
32	900 00 00-02	DUMMY PART	DUMMY PART	2
33	534 79 19-01	SEAL	SEAL	1
34	534 75 93-01	BEARING	BEARING	2
35	535 62 60-01	BLOCK	BLOCK	1

BMP 335
HEIGHT ADJUSTMENT





HEIGHT ADJUSTMENT

BMP 335, 2022-04

Ref	Part No	Description	Remark	QTY KIT
1	900 00 00-02	DUMMY PART	DUMMY PART	1
2	535 35 25-01	WHEEL	WHEEL	1
3	534 85 83-01	SPINDLE	SPINDLE	1
4	534 61 99-01	ADJUSTER	ADJUSTER	1
5	534 39 15-01	CLAMP	CLAMP	1
6	900 00 00-02	DUMMY PART	DUMMY PART	2
7	534 75 89-01	BEARING	BEARING	1
8	534 84 70-01	BLOCK	BLOCK	1
9	900 00 00-02	DUMMY PART	DUMMY PART	2
10	534 61 51-01	SCREW	SCREW	2
11	900 00 00-02	DUMMY PART	DUMMY PART	1
12	900 00 00-02	DUMMY PART	DUMMY PART	1
13	534 75 88-01	BEARING	BEARING	1
14	534 84 69-01	BLOCK	BLOCK	1
15	900 00 00-02	DUMMY PART	DUMMY PART	2
16	900 00 00-02	DUMMY PART	DUMMY PART	2
17	900 00 00-02	DUMMY PART	DUMMY PART	1
18	900 00 00-02	DUMMY PART	DUMMY PART	4
19	900 00 00-02	DUMMY PART	DUMMY PART	2
20	531 46 95-01	BUSHING	BUSHING	4
21	535 63 40-01	ELBOW	ELBOW	1
22	536981301	TBD	LEVER	1
23	535 21 74-01	MOUNTING PLATE	MOUNTING PLATE	1
24	531 48 45-01	BEARING	BEARING	2
25	535 21 81-01	MOUNTING PLATE	MOUNTING PLATE	1
26	535 19 29-02	HANDLE	HANDLE	1
27	533 89 75-01	BUSHING	BUSHING	1
28	533 27 17-01	LOCKING PIN	LOCKING PIN	1
29	900 00 00-02	DUMMY PART	DUMMY PART	1
30	533 91 63-01	HANDLE GRIP	HANDLE GRIP	1

BMP 335
HEIGHT ADJUSTMENT SUPPORT & DEPTH ADJUSTMENT




HEIGHT ADJUSTMENT

BMP 335, 2022-04

Ref	Part No	Description	Remark	QTY KIT
1	534 86 82-01	SPRING	SPRING	1
2	900 00 00-02	DUMMY PART	DUMMY PART	4
3	535 25 71-01	PLATE	PLATE	1
4	534 84 71-01	BLOCK	BLOCK	2
5	535 21 54-01	BLOCK	BLOCK	1
6	534 73 23-01	NIPPLE	NIPPLE	2
7	535 16 14-01	PLATE	PLATE	1
8	535 21 55-01	BLOCK	BLOCK	1
9	535 25 72-01	PLATE	PLATE	1
10	535 24 95-01	STUD	STUD	1
11	534 76 19-01	KNOB	KNOB	3
12	535 22 96-01	BAR	BAR	1
13	900 00 00-02	DUMMY PART	DUMMY PART	1
14	534 40 96-01	CONTROL CABLE	CONTROL CABLE	1
15	900 00 00-02	DUMMY PART	DUMMY PART	2
16	535 19 28-01	BRACKET	BRACKET	1
17	534 90 65-01	BUSH	BUSH	2
18	900 00 00-02	DUMMY PART	DUMMY PART	4
19	535 18 77-01	SUPPORT	SUPPORT	1
20	533 29 82-01	GAS SPRING	GAS SPRING	1
21	535 24 42-01	PLATE	PLATE	1

BMP 335
BEARING UNIT




BEARING HOUSING

BMP 335, 2022-04

Ref	Part No	Description	Remark	QTY KIT
1	533 88 33-01	SUPPORT	SUPPORT	1
2	534 85 56-01	SPACER	SPACER	1
3	533 33 79-01	SEAL	SEAL	2
4	533 21 81-01	CIRCLIP	CIRCLIP	2
5	534 31 56-01	BEARING HOUSING	BEARING HOUSING	1
6	533 84 35-01	NIPPLE	NIPPLE	1
7	533 61 12-01	BEARING	BEARING	1
8	534 85 57-01	SPACER	SPACER	1
9	900 00 00-02	DUMMY PART	DUMMY PART	3
10	534 66 44-01	BEARING	BEARING	1
11	536981401	TBD	GREASE	1

BMP 335
SIDE PLATE & BEARING UNIT




SIDE COVER

BMP 335, 2022-04

Ref	Part No	Description	Remark	QTY KIT
1	534 61 68-01	HANDLE	HANDLE	2
2	535 15 71-01	COVER	COVER	1
3	900 00 00-02	DUMMY PART	DUMMY PART	2
4	900 00 00-02	DUMMY PART	DUMMY PART	3
5	533 83 69-01	WASHER	WASHER	3
6	535 21 22-01	PLATE	PLATE	1
7	534 31 57-01	BEARING HOUSING	BEARING HOUSING	1
8	533 25 58-01	SEAL	SEAL	1
9	900 00 00-02	DUMMY PART	DUMMY PART	1
10	900 00 00-02	DUMMY PART	DUMMY PART	2
11	533 61 13-01	BEARING	BEARING	1
12	533 48 50-01	SUPPORT	SUPPORT	1
13	533 74 09-01	SEAL	SEAL	1
14	900 00 00-02	DUMMY PART	DUMMY PART	4
15	534 83 94-01	BRUSH	BRUSH	1
16	534 82 45-01	GASKET	GASKET	1
17	900 00 00-02	DUMMY PART	DUMMY PART	2
18	900 00 00-02	DUMMY PART	DUMMY PART	2
19	900 00 00-02	DUMMY PART	DUMMY PART	3
20	900 00 00-02	DUMMY PART	DUMMY PART	3
21	900 00 00-02	DUMMY PART	DUMMY PART	3
22	900 00 00-02	DUMMY PART	DUMMY PART	4
23	534 80 78-01	BEARING UNIT	BEARING UNIT	1


BMP 335
DRUMDRIVE - 11kW




DRUM MOTOR

BMP 335, 2022-04

Ref	Part No	Description	Remark	QTY KIT
1	534 71 15-01	MOTOR	MOTOR	1
2	535 21 73-01	MOUNTING PLATE	MOUNTING PLATE	1
3	534 86 35-01	SPACER RING	SPACER RING	1
4	534 63 76-01	PULLEY	PULLEY	1
5	534 31 94-01	BELT	BELT	1
6	534 72 51-01	BUSH	BUSH	1
7	900 00 00-02	DUMMY PART	DUMMY PART	1
8	533 86 73-01	BELT	BELT	1
9	900 00 00-02	DUMMY PART	DUMMY PART	1
10	533 58 73-01	SHAFT	SHAFT	1
11	533 46 01-01	KEY	KEY	1
12	534 63 75-01	PULLEY	PULLEY	1
13	900 00 00-02	DUMMY PART	DUMMY PART	2
14	900 00 00-02	DUMMY PART	DUMMY PART	3
15	900 00 00-02	DUMMY PART	DUMMY PART	2
16	535 21 44-02	PLATE	PLATE	1
17	900 00 00-02	DUMMY PART	DUMMY PART	2
18	535 35 70-01	LOCKING PIN	LOCKING PIN	1
19	534 57 15-01	EYE BOLT	EYE BOLT	1
20	900 00 00-02	DUMMY PART	DUMMY PART	2
21	900 00 00-02	DUMMY PART	DUMMY PART	2
22	900 00 00-02	DUMMY PART	DUMMY PART	1
23	535 21 51-01	AXLE	AXLE	1
24	900 00 00-02	DUMMY PART	DUMMY PART	1
25	900 00 00-02	DUMMY PART	DUMMY PART	4



Ref	Part No	Description	Remark	QTY KIT
1	535 18 19-02	FRAME	FRAME	1
2	535 25 11-01	SUPPORT	SUPPORT	1
3	535 19 27-01	AXLE	AXLE	2
4	535 24 14-01	BAR	BAR	2
5	900 00 00-02	DUMMY PART	DUMMY PART	2
6	533 84 82-01	ABSORBER	ABSORBER	2
7	533 25 64-01	PIN	PIN	1
8	535 25 80-01	CLAMP	CLAMP	1
9	900 00 00-02	DUMMY PART	DUMMY PART	2
10	533 76 77-01	PIPE CLAMP	PIPE CLAMP	2
11	900 00 00-02	DUMMY PART	DUMMY PART	4
12	900 00 00-02	DUMMY PART	DUMMY PART	2
13	535 24 50-01	BUSH	BUSH	2
14	533 27 84-01	SPRING	SPRING	2
15	900 00 00-02	DUMMY PART	DUMMY PART	2
16	900 00 00-02	DUMMY PART	DUMMY PART	2
17	900 00 00-02	DUMMY PART	DUMMY PART	12
18	535 25 48-01	SUPPORT	SUPPORT	1
19	533 25 06-01	BUSHING	BUSHING	2
20	533 83 69-01	WASHER	WASHER	2
21	900 00 00-02	DUMMY PART	DUMMY PART	2
22	900 00 00-02	DUMMY PART	DUMMY PART	2
23	533 21 40-01	HOOK	HOOK	3
24	534 75 74-01	PIPE CLAMP	PIPE CLAMP	1
25	534 67 73-01	WASHER	WASHER	2
26	900 00 00-02	DUMMY PART	DUMMY PART	4
27	534 87 49-01	HOSE	HOSE	1
28	900 00 00-02	DUMMY PART	DUMMY PART	2
29	535 15 70-02	COVER	COVER	1
30	900 00 00-02	DUMMY PART	DUMMY PART	4
31	535 18 55-01	PLATE	PLATE	1
32	900 00 00-02	DUMMY PART	DUMMY PART	16




WHEEL ASSY

BMP 335, 2022-04

Ref	Part No	Description	Remark	QTY KIT
1	535 18 38-01	BRACKET	BRACKET	1
2	900 00 00-02	DUMMY PART	DUMMY PART	7
3	900 00 00-02	DUMMY PART	DUMMY PART	4
4	534 51 31-01	INDICATOR	INDICATOR	1
5	900 00 00-02	DUMMY PART	DUMMY PART	1
6	534 51 33-01	PIPE	PIPE	1
7	900 00 00-02	DUMMY PART	DUMMY PART	1
8	533 51 21-01	CLAMP	CLAMP	1
9	534 51 32-01	INDICATOR	INDICATOR	1
10	900 00 00-02	DUMMY PART	DUMMY PART	2
11	534 39 08-01	CLAMP	CLAMP	2
12	534 34 16-01	BLOCK	BLOCK	1
13	534 38 54-01	WHEEL	WHEEL	3
14	900 00 00-02	DUMMY PART	DUMMY PART	12
15	900 00 00-02	DUMMY PART	DUMMY PART	12
16	900 00 00-02	DUMMY PART	DUMMY PART	12
17	533 72 29-01	RETAINER RING	RETAINER RING	2
18	535 64 13-01	BOLT	BOLT	2
19	900 00 00-02	DUMMY PART	DUMMY PART	2
20	900 00 00-02	DUMMY PART	DUMMY PART	2

BMP 335
ELECTROBOX





ELECTRIC BOX

BMP 335, 2022-04

Ref	Part No	Description	Remark	QTY KIT
1	534 34 39-01	ELECTRONIC BOX	ELECTRONIC BOX	1
2	900 00 00-02	DUMMY PART	DUMMY PART	1
3	900 00 00-02	DUMMY PART	DUMMY PART	4
4	533 91 51-01	CONTACTOR	CONTACTOR	1
5	534 02 60-01	HOUR METER	HOUR METER	1

BMP 335
SCARIFY DRUMS




DRUM

BMP 335, 2022-04

Ref	Part No	Description	Remark	QTY KIT
1	900 00 00-02	DUMMY PART	DUMMY PART	1
2	534 80 64-01	PLATE	PLATE	1
3	534 53 79-01	SHAFT	SHAFT	1
4	533 87 33-01	DRUM	DRUM	1
5	533 87 36-01	DRUM	DRUM	1


BMP 335
ASSEMBLY PLAN - MPD335-522L4S

3 spacer rings between cutters



Total: 244

83



MPL30

MPL24


ASSEMBLY

BMP 335, 2022-04

Ref	Part No	Description	Remark	QTY KIT
1	533 87 36-01	DRUM	DRUM	1
2	534 53 79-01	SHAFT	SHAFT	5
3	534 42 06-01	CUTTER	CUTTER	83
4	534 85 65-01	SPACER RING	SPACER RING	244

BMP 335
ASSEMBLY PLAN - MPD335-522L29S

4 spacer rings between cutters




Supporting bush for drum
MP07201

Ref	Part No	Description	Remark	QTY KIT
1	533 87 36-01	DRUM	DRUM	1
2	534 53 79-01	SHAFT	SHAFT	5
3	534 70 65-01	CUTTER	CUTTER	45
4	534 85 65-01	SPACER RING	SPACER RING	180
5	534 87 72-01	PLATE	PLATE	5


BMP 335
ASSEMBLY PLAN - MPD335-522L120S

3 spacer rings between cutters



Ref	Part No	Description	Remark	QTY KIT
1	533 87 36-01	DRUM	DRUM	1
2	534 53 79-01	SHAFT	SHAFT	5
3	533 12 53-01	TOOL	TOOL	83
4	534 85 65-01	SPACER RING	SPACER RING	244

BMC 335
DRUMHOUSING - 335 - MKII



DRUM

BMP 335, 2022-04

Ref	Part No	Description	Remark	QTY KIT
1	535 15 91-01	PLATE	PLATE	4
2	535 21 63-01	PIN	PIN	1
3	535 16 82-02	HOUSING	HOUSING	1
4	534 90 65-01	BUSH	BUSH	4
5	535 35 97-01	AXLE	AXLE	1
6	900 00 00-02	DUMMY PART	DUMMY PART	8
7	900 00 00-02	DUMMY PART	DUMMY PART	8
8	900 00 00-02	DUMMY PART	DUMMY PART	4
9	900 00 00-02	DUMMY PART	DUMMY PART	6
10	534 82 45-01	GASKET	GASKET	2
11	534 83 94-01	BRUSH	BRUSH	1
12	535 15 90-01	PLATE	PLATE	2
13	534 82 37-01	SEAL	SEAL	2
14	534 83 92-01	BRUSH	BRUSH	2
15	900 00 00-02	DUMMY PART	DUMMY PART	14
16	900 00 00-02	DUMMY PART	DUMMY PART	14
17	900 00 00-02	DUMMY PART	DUMMY PART	14
18	535 35 98-01	PIN	PIN	1
19	534 78 41-01	HOSE	HOSE	1
20	534 62 90-01	HOSE CLAMP	HOSE CLAMP	2